# Network Programming [CACS355] BCA 6th Sem

Er. Sital Prasad Mandal

(Email: info.sitalmandal@gmail.com)
Bhadrapur, Jhapa, Nepal

https://networkprogam-mmc.blogspot.com/

https://networkprogam-mmc.blogspot.com/

# Unit-11 IP Multicast

1	Multicasting
2	Multicast Addresses and Groups
3	Clients and Servers
4	Routers and Routing
5	Working with Multicast Sockets
6	The Constructors
7	Communicating with a Multicast Group

#### **IP Multicast**

- Supported by IPv4
  - one-to-one
  - one-to-all
  - one-to-many
- Not supported by IPv4:
  - one-to-any


(unicast) (multicast)

(anycast)


#### Multicast: 1 to many

Transfers packets from one source to many (broadcast) recipients. Multicast receivers only receive packets if they showed interest beforehand.


> The stream from the camera is unique and sent no more than once on a physical line when on the network.




Class A, B, C addresses



**Broadcast addresses** (e.g., 255, 255, 255, 255, 128 100 255 255)



Class D addresses




There are no anycast addresses

IP multicast also supports a many-to-many service.

- Internet Group Management Protocol(IGMP)
- IP multicast requires support of other protocols (IGMP, multicast routing)

## 1. Multicasting

- Multicasting: sends data from one host to many different hosts
  - Not to everyone: only clients expressing an interest by joining a multicast group
  - Examples:
    - Apple's Bonjour (a.k.a. Zeroconf) and Apache's River both use IP multicasting to dynamically discover services on the local network
- Most of the work is done by routers and transparent to programmers
  - The routers make sure the packet is delivered to all the hosts in the multicast group
    - The biggest problem is that not all routers support multicasting
  - Time-To-Live (TTL) of IP: maximum number of routers that the datagram is allowed



Destinations	TTL value
The local host	0
The local subnet	1
The local campus—that is, the same side of the nearest Internet router—but on possibly different LANs	16
High-bandwidth sites in the same country, generally those fairly close to the backbone	32
All sites in the same country	48
All sites on the same continent	64
High-bandwidth sites worldwide	128
All sites worldwide	255

### 2. Multicast Addresses and Groups

- A multicast address is the shared address of a group of hosts called a multicast group
  - IPv4 CIDR group: 224.0.0.0/4 (224.0.0.0 to 239.255.255.255)
    - All addresses have the leading four binary digits 1110
  - IPv6 CIDR group: ff00::/8
    - All start with the byte 0xFF, or 1111 1111 in binary
- A multicast group
  - Open: enter or leave at any time
  - Either permanent or transient
    - Permanent: the assigned address remains constant
      - -Assigned: **224.1.** or **224.2.**
      - -The complete list is available from iana.org
    - Transient: exist only as long as they have members
      - -Create a new multicast group address from **225.**0.0.0 to **238.**255.255.255
- Link-local multicast addresses: from 224.0.0.0 to 224.0.0.255
  - Packets addressed to a multicast group from 224.0.0.0 to 224.0.0.255 are never forwarded beyond the local subnet

### 2. Multicast Addresses and Groups

```
Address: 224.0.0.0
```

Netmask: 240.0.0.0 = 4

Wildcard: 15.255.255.255

=>

Network: 224.0.0.0/4

Broadcast: 239.255.255.255

HostMin: 224.0.0.1

HostMax: 239.255.255.254

Hosts/Net: 268435454

```
1110 0000.000000000.00000000.00000000
```

1111 0000.00000000.00000000.00000000

0000 1111.11111111.11111111.1111111

```
1110 0000.000000000.000000000.000000000 (Class D)
```

1110 1111.111111111.111111111.11111111

1110 0000.00000000.00000000.00000001

1110 1111.11111111.11111111.1111110

#### 2. Multicast Addresses and Groups

#### Table 13-1. Link-local Multicast Addresses

lomain name	IP address	Purpose
ASE-ADDRESS.MCAST.NET	224.0.0.0	The reserved base address. This is never assigned to any multicast group.
LL-SYSTEMS.MCAST.NET	224.0.0.1	All systems on the local subnet.
LL-ROUTERS.MCAST.NET	224.0.0.2	All routers on the local subnet.
VMRP.MCAST.NET	224.0.0.4	All Distance Vector Multicast Routing Protocol(DVMRP) routers on this subne
NOBILE-AGENTS.MCAST.NET	224.0.0.11	Mobile agents on the local subnet.
HCP-AGENTS.MCAST.NET	224.0.0.12	This multicast group allows a client to locate a Dynamic Host Configuration Protocol (DHCP) server or relay agent on the local subnet.
SVP- NCAPSULATION.MCAST.NET	224.0.0.14	RSVP encapsulation on this subnet. RSVP stands for Resource reSerVation setup Protocol, an effort to allow people to reserve a guaranteed amount of Internet bandwidth in advance for an event.
RRP.MCAST.NET	224.0.0.18	Virtual Router Redundancy Protocol (VRRP) Routers
	224.0.0.35	DXCluster is used to announce foreign amateur (DX) stations.
	224.0.0.36	Digital Transmission Content Protection (DTCP), a digital restrictions management (DRM) technology that encrypts interconnections between DVD players, televisions, and similar devices.
	224.0.0.37-224.0.0.68	zeroconf addressing
	224.0.0.106	Multicast Router Discovery
	224.0.0.112	Multipath Management Agent Device Discovery
	224.0.0.113	Qualcomm's AllJoyn
	224.0.0.114	Inter RFID Reader Protocol
	224.0.0.251	Multicast DNS self assigns and resolves hostnames for multicast addresses.
	224.0.0.252	Link-local Multicast Name Resolution, a precursor of mDNS, allows nodes ot self-assign domain names strictly for the local network, and to resolve such domain names on the local network.
	224.0.0.253	Teredo is used to tunnel IPv6 over IPv4. Other Teredo clients on the same IPv4 subnet respond to this multicast address.
	224.0.0.254	Reserved for experimentation.

### 2. Multicast Addresses and Groups

Domain name	IP address	Purpose
NTP.MCAST.NET	224.0.1.1	The Network Time Protocol.
NSS.MCAST.NET	224.0.1.6	The Name Service Server.
AUDIONEWS MCAST.NET	224.0.1.7	Audio news multicast.
MTP.MCAST.NET	224.0.1.9	The Multicast Transport Protocol.
IETF-1-LOW-AUDIO.MCAST.NET	224.0.1.10	Channel 1 of low-quality audio from IETF meetings.
IETF-1-AUDIO.MCAST.NET	224.0.1.11	Channel 1 of high-quality audio from IETF meetings.
IETF-1-VIDEO.MCAST.NET	224.0.1.12	Channel 1 of video from IETF meetings.
IETF-2-LOW-AUDIO.MCAST.NET	224.0.1.13	Channel 2 of low-quality audio from IETF meetings.
IETF-2-AUDIO:MCAST.NET	224.0.1.14	Channel 2 of high-quality audio from IETF meetings.
IETF-2-VIDEO.MCAST.NET	224.0.1.15	Channel 2 of video from IETF meetings.
MLOADO.MCAST.NET	224.0.1.19	MLOADD measures the traffic load through one or more network interfaces over a number of seconds. Multicasting is used to communicate between the different interfaces being measured.
EXPERIMENT.MCAST.NET	224.0.1.20	Experiments.
MICROSOFT.MCAST.NET MTRACE.MCAST.NET	224.0.23.178 224.0.1.24 224.0.1.32	JDP Java Discovery Protocol, used to find manageable JVMs on the network.  Usedby Windows Internet Name Service(WINS) servers to locate one anothe  A multicast version of traceroute.
JINI-ANNOUNCEMENT.MCAST.NET	224.0.1.84	JINI announcements.
JINI-REQUEST.MCAST.NET	224.0.1.85	JINI requests.
	224.0.1.143	Emergency Managers Weather Information Network.
	224.2.0.0-224.2.255.255	The Multicast Backbone on the Internet (MBONE) addresses are reserved for multimedia conference calls (i.e., audio, video, whiteboard, and shared web browsing between many people).
	224.2.2.2	Port 9875 on this address is used to broadcast the currently available MBONE programming. You can look at this with the X Window utility sdr or the Windows/Unix multikit program.
	239.0.0.0-239.255.255.255	Organization local scope, in contrast to TTL scope, uses different ranges of multicast addresses to constrain multicast traffic to a particular region or group of routers. For example, when a Universal Plug and Play (UPnP) device joins a network, it sends an HTTPU (HTTP over UDP) message to the multicast address
mmon Permanent M	ulticast Addresses	하다 생생 일반이 되는 이 가게 되었다면 하는 사람이 되었다면 하는 사람들이 되었다면 하는 것이 되었다면 하는데

on less-than-reliable TTL values.


Table 13-2. C

#### 3. Clients and Servers

- Send
  - Once the data has been stuffed into one or more datagrams, the sending host launches the datagrams onto the Internet like sending regular UDP data
- Receive
  - When data arrives at a host in a multicast group, the host receives it as it receives any other UDP datagram

### 4. Routers and Routing

- Mrouters: the biggest restriction on multicasting is the availability of special multicast routers
  - For packets to reach any given host, there must be a path of multicast capable routers between your host and the remote host



#### 5. Working with Multicast Sockets

#### Java.net.MulticastSocket

- Steps to receive multicast data
- public class MulticastSocket extends DatagramSocket implements Closeable, AutoCloseable
- 1. MulticastSocket(): create a MulticastSocket with its constructor

```
MulticastSocket ms = new MulticastSocket(2300);
```

2. joinGroup(): join a multicast group

```
InetAddress group = InetAddress.getByName("224.2.2.2");
ms.joinGroup(group);
```

3. Receive UDP data just as with a DatagramSocket and DatagramPacket

```
byte[] buffer = new byte[8192];
DatagramPacket dp = new DatagramPacket(buffer, buffer.length);
ms.receive(dp);
```

- 4. leaveGroup(): leave the multicast group
- Close socket with close()

```
ms.leaveGroup(group);
ms.close();
```

- Steps to send multicast data: similar to sending UDP data
  - Create a MulticastSocket and directly send data to it
    - Do not need to join a multicast group

```
InetAddress ia = InetAddress.getByName("experiment.mcast.net");
byte[] data = "Here's some multicast data\r\n".getBytes("UTF-8");
int port = 4000;
DatagramPacket dp = new DatagramPacket(data, data.length, ia, port);
MulticastSocket ms = new MulticastSocket();
ms.send(dp);
```

#### 7. Communicating with a Multicast Group

```
    3 constructors

      public MulticastSocket() throws SocketException
      public MulticastSocket(int port) throws SocketException
      public MulticastSocket(SocketAddress bindAddress) throws IOException
  -bind()
      MulticastSocket ms = new MulticastSocket(null);
      ms.setReuseAddress(false):
      SocketAddress address = new InetSocketAddress(4000):
      ms.bind(address):

    joinGroup(): join a group

     public void joinGroup(InetAddress address) throws IOException
     public void joinGroup(SocketAddress address, NetworkInterface interface)
         throws IOException

    A single MulticastSocket can join multiple multicast groups

    Multiple multicast sockets (on same or different JVMs) can all join the same group

    leaveGroup(): leave a group

                                                                         Java 6-
      public void leaveGroup(InetAddress address) throws IOException
                                                                         MulticastSocket socket = null;
      public void leaveGroup(SocketAddress multicastAddress,
                                                                           socket = new MulticastSocket();
```

throws IOException close(): close the socket

```
NetworkInterface interface)
                                                                                           // connect to the server...
                                                                                          } catch (IOException ex) {
                                                                                            ex.printStackTrace();
                                            Java 7+
                                                                                         } finally {
                                                                                           if (socket != null) {
                                try (MulticastSocket socket = new MulticastSocket()) {
                                  // connect to the server...
                                                                                                socket.close();
                                } catch (IOException ex) {
                                                                                              } catch(IOException ex){//ignore
                                  ex.printStackTrace();
```

#### 7. Communicating with a Multicast Group

- Sending: multicast sockets uses a TTL of 1 by default
  - -setTimeToLive(): set the default TTL

- -setLoopBack(): Set not to receive packets you sends (default is platform dependent) public void setLoopbackMode(boolean disable) throws SocketException public boolean getLoopbackMode() throws SocketException
- setInterface(), setNetworkInterface(): specify a network interface for multicast

MulticastSocket ms = new Multicast:
 ms.setInterface(ia);
 // send and receive data...
} catch (UnknownHostException ue) {
 System.err.println(ue);
} catch (SocketException se) {
 System.err.println(se);
}

**Sending Multicast Data** 

# Unit-11 MulticastClient

```
import java.io.IOException;
import java.net.DatagramPacket;
import java.net.InetAddress;
import java.net.MulticastSocket;
import java.net.UnknownHostException;
public class MulticastClient {
    final static String INET_ADDR = "224.0.0.3";
    final static int PORT = 8888;
    public static void main(String[] args) throws UnknownHostException {
        InetAddress address = InetAddress.getByName(INET ADDR);
        byte[] buf = new byte[256];
        try(MulticastSocket cs = new MulticastSocket(PORT)){
            cs.joinGroup(address);
            while (true){
                 DatagramPacket msgPacket = new DatagramPacket(buf,buf.length);
                 cs.receive(msgPacket);
                 String msg = new String(buf, 0, buf.length);
                 System.out.println("Socket 1 recived msg:" + msg);
        }catch (IOException ex){
            ex.printStackTrace();
```

https://networkprogam-mmc.blogspot.com/

# Unit-11 MulticastServer

```
import java.io.IOException;
import java.net.*;
public class MulticastServer {
    final static String INET_ADDR = "224.0.0.3";
    final static int PORT = 8888;
    public static void main(String[] args) throws UnknownHostException, InterruptedException {
        InetAddress addr = InetAddress.getByName(INET_ADDR);
        try (DatagramSocket ss = new DatagramSocket()) {
          for(int i=0;i<5;i++){</pre>
              String msg = "Sent Message server no" + i;
                DatagramPacket msgPacket = new
DatagramPacket(msg.getBytes(),msg.getBytes().length,addr,PORT);
                ss.send(msgPacket);
                System.out.println("Socket 1 recived msg:" + msg);
                Thread.sleep(500);
        } catch (IOException ex) {
            ex.printStackTrace();
        }
```

# Unit-11<br/>Summary

#### 13.1 Multicasting

- Multicast group and addresses
- 13.2 Working with Multicast Sockets
  - –Java.net.MulticastSocket
  - -joinGroup(), leaveGroup(), bind(), close()

#### 13.3 Two Simple Examples

-MulticastSniffer (Example 13-1), MulticastSender (Example 13-2)